


# 福岡進入管制区

## Fukuoka Approach Control Area



### Point list

(1) 331929N1301048E	(11) 335111N1304558E	(21) 340937N1294200E	(31) 335905N1305538E
(2) 330951N1300318E	(12) 334621N1302850E	(22) 334508N1294656E	(32) 335327N1305356E
(3) 330147N1301316E	(13) 330353N1303303E	(23) 340007N1294626E	(33) 341128N1310245E
(4) 330132N1302113E	(14) 330533N1310128E	(24) 334447N1292857E	(34) 341648N1310822E
(5) 330915N1302028E	(15) 334228N1304858E	(25) 332519N1300516E	(35) 341502N1305813E
(6) 333611N1304424E	(16) 335247N1305140E	(26) 332231N1293403E	(36) 330615N1293818E
(7) 332944N1304800E	(17) 334351N1305445E	(27) 334138N1292902E	(37) 330921N1295252E
(8) 333437N1305145E	(18) 335836N1311215E	(28) 330309N1302104E	(38) 332024N1300955E
(9) 334458N1305945E	(19) 334829N1311425E	(29) 335135N1304720E	
(10) 334047N1304149E	(20) 341554N1305655E	(30) 340133N1305404E	