

(誤) 表44

構造形式別、都道府県別橋梁の現況 <<国・都道府県道>>

(単位:箇所、m、%)

Table with 10 columns for prefectures and 10 columns for bridge types. Rows list prefectures from Hokkaido to Okinawa, with detailed statistics for each bridge type.

(正) 表44

構造形式別、都道府県別橋梁の現況 <<国・都道府県道>>

(単位:箇所、m、%)

Table with 10 columns for prefectures and 10 columns for bridge types. Rows list prefectures from Hokkaido to Okinawa, with detailed statistics for each bridge type.